

Professional Digital Two-Way Radio System

# **MOTOTRBO™** DM 3600 / DM 3601 Display Mobile

Quick Reference Guide





## DM 3600/3601 Mobiles Quick Reference Guide

### Important Safety Information

#### Product Safety and RF Exposure Compliance



Caution

Before using this product, read the operating instructions for safe usage contained in the Product Safety and RF Exposure booklet enclosed with your radio.

#### ATTENTION!

**This radio is restricted to occupational use only to satisfy FCC/ICNIRP RF energy exposure requirements.** Before using this product, read the RF energy awareness information and operating instructions in the Product Safety and RF Exposure booklet enclosed with your radio (Motorola Publication part number 6866537D37) to ensure compliance with RF energy exposure limits.

For a list of Motorola-approved antennas, batteries, and other accessories, visit the following website:

<http://www.motorola.com/governmentandenterprise>

6866575D02-E



### ■ Your Quick Reference Guide

This Quick Reference Guide covers the basic operation of the MOTOTRBO Mobile.

However, your dealer or system administrator may have customized your radio for your specific needs. Check with your dealer or system administrator for more information.

Throughout this publication, two icons are used to differentiate Analog mode and Digital mode only features:



Indicates a conventional **Analog Mode-Only** feature.



Indicates a conventional **Digital Mode-Only** feature.

**NOTE:** For features that are available in **both** conventional Analog and Digital modes, **no** icon is shown.


Selected features are also available on the single-site trunking mode, Capacity Plus.

### ■ Radio Controls

Record your radio's programmable button functions in the blanks provided.

**SP** represents Short Press.

**LP** represents Long Press.



- 1 On/Off Button
- 2 Volume Knob
- 3 Front Button P1 (Programmable)  
**SP:** \_\_\_\_\_  
**LP:** \_\_\_\_\_
- 4 Display
- 5 Channel Rocker
- 6 Speaker

7 Front Button P3 (Programmable)  
SP: \_\_\_\_\_  
LP: \_\_\_\_\_

8 Front Button P4 (Programmable)  
SP: \_\_\_\_\_  
LP: \_\_\_\_\_


9 Menu Navigation Buttons

10 Front Button P2 (Programmable)  
SP: \_\_\_\_\_  
LP: \_\_\_\_\_

11 Accessory Connector

12 LED Indicators

## Menu Navigation Buttons



A Left/Right Navigation Buttons


B Menu Button


C OK Button


D Back/Home Button


## Display Icons


The following are the icons that appear on the radio's display.


 The number of bars displayed represents the radio signal strength. Four bars indicates the strongest signal. This icon is only displayed while receiving.



 Selected channel is being monitored.

 Radio is currently set at Low Power (L) or High Power (H).


 Tones are set off.


 The Option Board is enabled.

 The Option Board is disabled.



 The GPS feature is enabled. The icon stays lit when a position fix is available. 


 The GPS feature is enabled but is not receiving data from the satellite. 



 Scan feature is activated.\*


 Radio recognizes activity on the channel/group designated as Priority 1 (if • is blinking) or as Priority 2 (if • is steady).\*



 Unread message in the Inbox. 


 User's Inbox is full. 

 Radio is in Emergency mode.

 The Privacy feature is enabled. 

 The Privacy feature is disabled. 

 The Site Roaming feature is enabled.\* 

 In the absence of a repeater, radio is currently configured for direct radio to radio communication.\*

\* Not applicable in Capacity Plus

## ■ Call Icons

The following icons appear on the radio's display during a call. These icons also appear in the Contacts list to indicate ID type.



Indicates a Private Call in progress. In Contacts list, it indicates a subscriber alias or ID.



Indicates a Group Call or All Call in progress. In Contacts list, it indicates a group alias or ID.

## ■ Sent Items Icons

The following icons appear at the top right corner of the radio's display in the Sent Items folder.



The text message is sent successfully.



The text message cannot be sent.



- The text message to a group alias or ID is pending transmission.
- The text message to a subscriber alias or ID is pending transmission, followed by waiting for acknowledgement.

## ■ LED Indicators

**Blinking red** – Radio is receiving an Emergency transmission or has failed the self-test upon powering up.

**Solid yellow** – Radio is receiving a request for a Private Call, or monitoring a channel.

**Blinking yellow** – Radio is scanning for activity or receiving a Call Alert.

**Double blinking yellow** – Radio is no longer connected to the repeater while in Capacity Plus or all Capacity Plus channels are currently busy.

**Rapidly blinking yellow** – Radio is searching for a new site.

**Solid green** – Radio is transmitting.

**Blinking green** – Radio is powering up, receiving a non-privacy-enabled call or data, or detecting activity over the air.

**Rapidly blinking green** – Radio is receiving a privacy-enabled call or data.

*For Capacity Plus, there is no LED indication when the radio is detecting activity over the air.*

## ■ Powering the Radio On or Off

Press the On/Off Button briefly to turn on the radio, and press and hold the On/Off Button to turn it off.

## ■ Adjusting the Volume

Turn the Volume Knob clockwise to increase volume or counterclockwise to decrease volume.

## ■ Selecting a Zone

Press the programmed **Zone** button and proceed to Step 3.

**OR**

Follow the procedure below.

- 1 to access the menu.
- 2 or to Zone and press to select.
- 3 The current zone is displayed and indicated by a ✓.
- 4 or to the required zone and press to select.
- 5 The display shows <Zone> Selected momentarily and returns to the selected zone screen.

## ■ Selecting a Radio Channel, Subscriber ID, or Group ID

- 1 Press the On/Off Button.
- 2 Press the Channel Rocker to select the required channel, subscriber ID, or group ID.








## ■ Capacity Plus


Press the Channel Rocker to access channels with Capacity Plus.



## ■ Making a Group Call

Press the programmed **One Touch Access** button and proceed to Step 2.  
**OR**


Follow the procedure below.

- 1 Press the Channel Rocker to select the channel with the active group alias or ID.  
**OR**  
 to access the menu.  
 or  to **Contacts** and press  to select.  
 or  to the ID you want to call and press  to select.
- 2 Press the **PTT** button to make the call. The green LED lights up. The display shows the group alias or ID, and the Group Call icon.

- 3 Wait for the Talk Permit Tone to finish (if enabled).  
**OR**  
 Wait for the **PTT** Sidetone to finish (if enabled).
- 4 Speak clearly into the microphone.
- 5 Release the **PTT** button to listen.
- 6 When the target radio responds, the green LED blinks. You see the Group Call icon, the group ID, and target radio ID on your display.

- 7  If the Channel Free Indication feature is enabled, you will hear a short alert tone the moment the target radio releases the **PTT** button, indicating the channel is free for you to respond. Press the **PTT** button to respond.  
**OR**  
 If the Voice Interrupt feature is enabled, press the **PTT** button to stop the current call from the transmitting radio and free the channel for you to talk/respond.  
**OR**  
If there is no voice activity for a programmed period of time, the call ends.








*To make a call to a group of users, your radio must be configured as part of that group.*

 Your radio must have the Privacy feature enabled on the channel to send a privacy-enabled transmission. Only target radios with the same Privacy Key **OR** the same Key Value and Key ID as your radio will be able to unscramble the transmission.

## ■ Making a Private Call

**NOTE:** Your radio must be programmed for you to initiate a Private Call.

Press the programmed **One Touch Access** button and proceed to Step 2.  
**OR**  
Follow the procedure below.

- 1 Press the Channel Rocker to select the channel with the active subscriber alias or ID.  
**OR**  
 to access the menu.  
 or  to **Contacts** and press  to select.  
 or  to the ID you want to call and press  to select.
- 2 Press the **PTT** button to make the call. The green LED lights up. The first line displays the target radio's ID. The


second line displays **Private Call** and the Private Call icon.

- 3 Wait for the Talk Permit Tone to finish (if enabled). Speak clearly into the microphone.
- 4 Release the **PTT** button to listen.
- 5 If the Channel Free Indication feature is enabled, you will hear a short alert tone the moment the target radio releases the **PTT** button, indicating the channel is free for you to respond. Press the **PTT** button to respond.  
**OR**  
If the Voice Interrupt feature is enabled, press the **PTT** button to stop the current call from the transmitting radio and free the channel for you to talk/respond.  
**OR**  
If there is no voice activity for a programmed period of time, the call ends.
- 6 You hear a short tone. The display shows **Call Ended**.

*Your radio must have the Privacy feature enabled on the channel to send a privacy-enabled transmission. Only target radios with the same Privacy Key OR the same Key Value and Key ID as your radio will be able to unscramble the transmission.*

## ■ Making an All Call

Your radio must be programmed to allow you to use this feature. Users on the channel cannot respond to an All Call.

- 1 Press the Channel Rocker to select the channel with the active All Call group alias or ID.
- 2 Press the **PTT** button to make the call. The green LED lights up. The display shows the All Call group alias or ID, and the All Call icon
- 3 Wait for the Talk Permit Tone to finish (if enabled).  
**OR**  
 Wait for the **PTT** Sidetone to finish (if enabled).
- 4 Speak clearly into the microphone.
- 5 If there is no voice activity for a programmed period of time, the call ends.

*When you **receive** an All Call, a message appears and remains on your radio's display until the call ends. You will not be able to continue with any menu navigation or editing until the call ends.*

*Once the All Call ends, the radio returns to the menu prior to receiving the call.*





## ■ Scanning Channels

**NOTE:** This feature is not applicable in Capacity Plus.

Press the programmed **Scan** button to turn scan on or off.

**OR**

Follow the procedure below.

- 1  to access the menu.
- 2  or  to **Scan** and press  to select.
- 3 You see **Scan On** or **Scan Off** depending on previous selection.











*During scan, the yellow LED blinks and the scan icon is displayed.*

## ■ Making a Call Alert

Press the programmed **One Touch Access** button and proceed to Step 5.

**OR**

Follow the procedure below.

- 1  to access the menu.
- 2  or  to **Contacts**. Press  to select.
- 3  or  to the required subscriber alias or ID and press  to select.
- 4  or  to **Call Alert** and press  to select.

5 The display shows Call Alert:  
<Subscriber Alias or ID>. The  
green LED lights up.

6 If the Call Alert acknowledgement is  
received, a tone sounds and the  
display shows Call Alert  
Successful.

**OR**

If the Call Alert acknowledgement is  
not received, a tone sounds and the  
display shows Call Alert Failed.

## Sending a Quick Text

### Message


Press the programmed **Text Messaging**  
button and proceed to Step 3.




**OR**




Press the programmed **One Touch**  
**Access** button to send a predefined  
Quick Text message to a predefined alias  
or ID and proceed to Step 6.




**OR**




Follow the procedure below.

1  to access the menu.

2  or  to Messages and press  to select.

3  or  to Quick Text and press  
 to select.

4  or  to the required Quick Text  
and press  to select.

5  or  to the required alias or ID  
and press  to select.


6 The display shows Text Message:  
<Subscriber/Group Alias or ID>.

7 If the message is sent successfully, a  
tone sounds and the display shows  
Message Sent.

**OR**

If the message cannot be sent, the  
display shows Message Send  
Failed.

*If the message fails to send, the radio  
returns you to the Resend option screen.*

- Press  to resend the message to the  
same subscriber/group alias or ID.
- Select *Forward* to send the message to  
another subscriber/group alias or ID.
- Select *Edit* to edit the message before  
sending it.

**NOTE:** Once a message is sent to  
another radio, it is saved in Sent  
Items. The most recent sent text  
message is always added to the  
top of the Sent Items list.

The Sent Items folder stores a  
maximum of thirty (30) last sent

messages. When the folder is full,  
the next sent text message  
automatically replaces the oldest  
text message in the folder.

The icon at the top right corner of  
the screen indicates the status of  
the message.




## Replying to a Text Message with Quick Text from the Inbox




Press the programmed **Text Messaging**  
button and proceed to Step 3.




**OR**


Follow the procedure below.




1  to access the menu.

2  or  to Messages and press  to select.

3  or  to Inbox. Press  to  
select.

4  or  to the required message  
and press  to select.  
A subject line may be shown if the  
message is from an e-mail application.

5 Press  once more to access the  
sub-menu.

6  or  to Reply and press  to  
select.

7 or to Quick Text and press to select.

---

8 Press once more to send the reply.

---

9 The display shows Text Message:  
<Subscriber/Group Alias or ID>.

---

10 If the message is sent successfully, a tone sounds. The display shows Message Sent.

**OR**

If the message cannot be sent, the display shows Message Send Failed.

---

*If the message fails to send, the radio returns you to the **Resend** option screen.*

- Press to resend the message to the same subscriber/group alias or ID.
- Select **Forward** to send the message to another subscriber/group alias or ID.
- Select **Edit** to edit the message before sending it.

## ■ Sending an Emergency Alarm

1 Press the programmed **Emergency** button or the **Emergency** footswitch.

---

2 The display shows Sending Alarm, which alternates with your radio ID. The green LED lights up and the Emergency icon appears on the Home screen display.

---

3 When an Emergency Alarm acknowledgment is received, the Emergency tone sounds and the green LED blinks. The display shows Emergency Alarm Successful.

**OR**

If your radio does not receive an Emergency Alarm acknowledgement, and after all retries have been exhausted, a tone sounds and the display shows Emergency Alarm Failed.

---

4 Radio exits the Emergency Alarm mode and returns to the Home screen.

---

*If your radio is set to Silent, it will not display any audio or visual indicators during Emergency mode.*

## ■ Privacy

Press the programmed **Privacy** button to toggle privacy on or off.

**OR**

Follow the procedure below.

1 to access the menu.

---

2 or to Utilities. Press to select.

---

3 or to Radio Settings. Press to select.

---

4 or to Privacy. Press to select.

---

5 The display shows Privacy and Turn On. Press to enable privacy. The display shows Privacy On.

**OR**

The display shows Privacy and Turn Off. Press to disable privacy. The display shows Privacy Off.

---

## ■ IP Site Connect

**NOTE:** This feature is not applicable in Capacity Plus.

Press the programmed **Site Lock On/Off** button to toggle automatic site roaming on or off.

**OR**

Follow the procedure below.

1 to access the menu.

---

2 or to Utilities. Press to select.

---




3 or to Radio Settings. Press to select.

---

4 or to Site Roaming. Press to select.




---



- 5  or  to Unlock Site. Press  to select. The display shows Site Unlocked.

The yellow LED blinks rapidly when the radio is actively searching for a new site, and turns off once the radio locks on to a site. The display shows the site roaming icon.

OR












-  or  to Lock Site. Press  to select. The display shows Site Locked. The LED turns off.

OR

Press the programmed **Manual Site Roam** button and proceed to Step 6.

OR

Follow the procedure below.

- 1  to access the menu.
- 2  or  to Utilities. Press  to select.
- 3  or  to Radio Settings. Press  to select.
- 4  or  to Site Roaming. Press  to select.
- 5  or  to Active Search. Press  to select.
- 6 A tone sounds. The display shows Finding Site. The green LED blinks.

- 7 If a new site is found, a tone sounds, and the LED turns off. The display shows Site <Alias> Found.

OR

If there is no available site within range, a tone sounds, and the LED turns off. The display shows Out of Range.

OR

If a new site is within range, but the radio is unable to connect to it, a tone sounds, and the LED turns off. The display shows Channel Busy.

- 8 The radio returns to the Home screen.

## Computer Software Copyright

The products described in this manual may include copyrighted computer programmes stored in semiconductor memories or other media. Laws in the United States of America and other countries preserve for Motorola Europe and Motorola Inc. certain exclusive rights for copyrighted computer programmes, including the right to copy or reproduce in any form the copyrighted computer programme. Accordingly, any copyrighted computer programmes contained in the products described in this manual may not be copied or reproduced in any manner without the express written permission of the holders of the rights. Furthermore, the purchase of these products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any licence under the copyrights, patents, or patent applications of the holders of the rights, except for the normal non-exclusive royalty free licence to use that arises by operation of the law in the sale of the product.