**PROFESSIONAL DIGITAL TWO-WAY RADIO**

# MOTOTRBO™
# SL SERIES
## SL4000 & SL4010 PORTABLES
## QUICK REFERENCE GUIDE

(EN) (DE) (FR) (IT) (ES) (PR) (NL) (DA) (SV)
(SF) (HU) (GK) (TU) (CZ) (PL) (RO) (RU) (AR)

# MOTOROLA

## SL4000 Series Portables Quick Reference Guide

### Important Safety Information

**Product Safety and RF Exposure Compliance**

### Computer Software Copyright

### Your Quick Reference Guide

This Quick Reference Guide covers an overview of the SL4000 Series Portable Radios. For more operational details, refer to the User Guide (Motorola publication number 68012004075).

Check with your dealer or system administrator because your radio will have been customized for your specific needs.

### Powering Up and Turning Off the Radio

Press the On/Off power button ⌾ on the front keypad.

### Adjusting the Volume

To increase the volume, push the Volume Button up.

To decrease the volume, push the Volume Button down.

## Radio Controls

Record your radio's programmable button functions in the blanks provided.

**SP** represents Short Press.
**LP** represents Long Press.



1. LED Indicator
2. Push-to-Talk (**PTT**) Button
3. Display
4. Microphone
5. Volume Button
6. P1 Button (Programmable)
   **SP**: _____ **LP**: _____
7. On/Off Button
8. Emergency Button (Programmable)
9. 4-way Navigation Disc
10. Antenna
11. Speaker
12. P2 Button (Programmable)
    **SP**: _____ **LP**: _____
13. Back/Home Button
14. Menu/OK Button
15. Keypad

## LED Indicator

**Blinking red** – Radio is receiving an Emergency transmission or has failed the self-test upon powering up.

**Solid yellow** – Radio is monitoring a digital conventional channel. Also indicates fair battery charge when the programmed button is pressed.

**Blinking yellow** – Radio is scanning for activity or receiving a Call Alert.

**Double blinking yellow** – Radio no longer detects repeater in Capacity Plus mode, all Capacity Plus channels currently busy, radio in locked state, radio actively searching for a new site, or radio has yet to respond to group call alert.

**Solid green** – Radio is powering up or transmitting. Also indicates full charge of the battery when the programmed button is pressed.

**Blinking green** – Radio is powering up, receiving a non-privacy-enabled call or data, or detecting activity over the air.

**Double blinking green** – Radio is receiving a privacy-enabled call or data.

**MOTOROLA**

www.motorolasolutions.com/mototrbo

**68012004073-A**